




# G0506X/G0506X3 Lower Frame and Motor




# G0506X/G0506X3 Lower Wheel Assembly




# G0506X/G0506X3 Table and Blade Guides



## G0506X/G0506X3 Upper Frame Assembly



# G0506X/G0506X3 Upper Wheel Assembly



# G0506X/G0506X3 Parts List

| REF   | PART #        | DESCRIPTION                       |
|-------|---------------|-----------------------------------|
| 1     | P0506001      | FRAME                             |
| 2     | P0506002      | HINGE PIN                         |
| 3     | P0506003      | UPPER WHEEL GUARD                 |
| 4     | P0506004      | LOWER WHEEL GUARD                 |
| 5     | PSB17         | CAP SCREW 1/4-20 X 3/8            |
| 6     | P0506006      | WHEEL GUARD LOCK KNOB             |
| 7     | PSB05         | CAP SCREW 1/4-20 X 3/4            |
| 8     | PN05          | HEX NUT 1/4-20                    |
| 9     | P0506X009     | MOTOR 3HP, 1 PHASE (G0506X)       |
| 9     | P0506X3009    | MOTOR 3HP, 3 PHASE (G0506X3)      |
| 9-1   | P0506X009-1   | MOTOR FAN (G0506X)                |
| 9-1   | P0506X3009-1  | MOTOR FAN (G0506X3)               |
| 9-2   | P0506X009-2   | FAN COVER (G0506X)                |
| 9-2   | P0506X3009-2  | FAN COVER (G0506X3)               |
| 9-3   | P0506X009-3   | JUNCTION BOX (G0506X)             |
| 9-3   | P0506X3009-3  | JUNCTION BOX (G0506X3)            |
| 9-4   | P0506X009-4   | START CAPACITOR 400MFD-125VAC     |
| 9-5   | P0506X009-5   | RUN CAPACITOR 30MFD, 300VAC       |
| 10    | PK43M         | KEY 8 X 8 X 45                    |
| 11    | P0506011      | MOTOR PULLEY                      |
| 12    | PSS08         | SET SCREW 5/16-18 X 1/2           |
| 13    | P0506013      | MOTOR FLANGE                      |
| 14    | P0506X014     | SPECIAL BOLT 3/8-16 X 1-1/4       |
| 15    | PN08          | HEX NUT 3/8-16                    |
| 17    | PW02          | FLAT WASHER 3/8                   |
| 18    | PLW04         | LOCK WASHER 3/8                   |
| 23    | PVA37         | V-BELT A-37 4L370                 |
| 24    | P0506024      | DUST BOARD                        |
| 25    | P0506025      | WOOD BOARD                        |
| 26    | PB07          | HEX BOLT 5/16-18 X 3/4            |
| 27    | PW07          | FLAT WASHER 5/16                  |
| 28    | PN02          | HEX NUT 5/16-18                   |
| 29    | PS06          | PHLP HD SCR 10-24 X 3/8           |
| 30    | P0506030      | DUST PORT                         |
| 31    | PS06          | PHLP HD SCR 10-24 X 3/8           |
| 32    | P0506032      | BLADE TENSION SCALE               |
| 33    | PSB41         | CAP SCREW 10-24 X 1/2             |
| 34    | P0506034      | WIRE BRACKET                      |
| 35    | PS06          | PHLP HD SCR 10-24 X 3/8           |
| 36    | PB58          | HEX BOLT 3/8-16 X 2               |
| 37    | PN08          | HEX NUT 3/8-16                    |
| 38    | P0506X038     | MAG SWITCH 3HP-1 PH, 22A (G0506X) |
| 38    | P0506X3038    | MAG SWITCH 3HP-3 PH, 9A (G0506X3) |
| 38-1  | P0506X038-1   | MAG SWITCH BACK COVER (G0506X)    |
| 38-1  | P0506X3038-1  | MAG SWITCH BACK COVER (G0506X3)   |
| 38-2  | P0506X038-2   | CONTACTOR (G0506X)                |
| 38-2  | P0506X3038-2  | CONTACTOR (G0506X3)               |
| 38-3  | P0506X038-3   | THERMAL OVERLOAD RELAY (G0506X)   |
| 38-3  | P0506X3038-3  | THERMAL OVERLOAD RELAY (G0506X3)  |
| 38-4  | P0506X038-4   | MAG SWITCH FRONT COVER (G0506X)   |
| 38-4  | P0506X3038-4  | MAG SWITCH FRONT COVER (G0506X3)  |
| 38A   | P0506X3038A   | MAG SWITCH (440V-5A, G0506X3)     |
| 38A-1 | P0506X3038A-1 | MAG SWITCH BACK COVER (G0506X3)   |

| REF   | PART #        | DESCRIPTION                      |
|-------|---------------|----------------------------------|
| 38A-2 | P0506X3038A-2 | CONTACTOR (G0506X3)              |
| 38A-3 | P0506X3038A-3 | THERMAL OVERLOAD RELAY (G0506X3) |
| 38A-4 | P0506X3038A-4 | MAG SWITCH FRONT COVER (G0506X3) |
| 39    | P0506039      | ON SWITCH (GREEN)                |
| 40    | P0506040      | OFF SWITCH (RED)                 |
| 41    | P0506041      | POWER CONTROL PANEL              |
| 42    | PS06          | PHLP HD SCR 10-24 X 3/8          |
| 43    | P0506043      | CONNECTION PLATE                 |
| 44    | P0506044      | BRAKE LINING                     |
| 45    | PB18          | HEX BOLT 3/8-16 X 1              |
| 46    | PB19          | HEX BOLT 1/4-20 X 1/2            |
| 47    | P0506047      | FOOT BRAKE PEDAL                 |
| 48    | PLW04         | LOCK WASHER 3/8                  |
| 49    | PN08          | HEX NUT 3/8-16                   |
| 50    | P0506050      | HELICAL SPRING 110MM             |
| 51    | PN08          | HEX NUT 3/8-16                   |
| 52    | PB18          | HEX BOLT 3/8-16 X 1              |
| 53    | P0506053      | STOP SWITCH                      |
| 54    | PSB22M        | CAP SCREW M4-.7 X 35             |
| 55    | P0506055      | UPPER WHEEL                      |
| 56    | P0506056      | UPPER WHEEL SHAFT                |
| 57    | P6205         | BALL BEARING 6205ZZ              |
| 58    | P0506058      | IN BUSHING                       |
| 59    | P0506059      | OUT BUSHING                      |
| 60    | PR26M         | INT RETAINING RING 52MM          |
| 61    | P0506061      | SPECIAL FLAT WASHER 10MM         |
| 62    | PB07          | HEX BOLT 5/16-18 X 3/4           |
| 63    | P0506063      | TIRE                             |
| 64    | P0506064      | LOWER WHEEL                      |
| 65    | P0506065      | LOWER WHEEL SHAFT                |
| 66    | P0506066      | BRUSH BRACKET*                   |
| 67    | P0506067      | BRUSH                            |
| 68    | PB03          | HEX BOLT 5/16-18 X 1             |
| 69    | PW07          | FLAT WASHER 5/16                 |
| 70    | PN02          | HEX NUT 5/16-18                  |
| 71    | P0506071      | SPECIAL WASHER 3/8~2             |
| 72    | PB21          | HEX BOLT 3/8-16 X 3/4            |
| 73    | PB24          | HEX BOLT 3/8-16 X 1-1/4          |
| 74    | PN08          | HEX NUT 3/8-16                   |
| 75    | P0506075      | ARBOR BRACKET                    |
| 76    | PB42          | HEX BOLT 1/2-12 X 2              |
| 77    | PN06          | HEX NUT 1/2-12                   |
| 78    | P0506078      | BLADE TENSION SHAFT              |
| 79    | P51104        | THRUST BEARING 51104             |
| 82    | P0506082      | INDICATOR WIRE PULLER            |
| 83    | P0506083      | HELICAL SPRING 50MM              |
| 84    | P0506084      | BRACKET HOLDER                   |
| 85    | PN06          | HEX NUT 1/2-12                   |
| 86    | PW01          | FLAT WASHER 1/2                  |
| 87    | P0506087      | BRACKET SHAFT                    |
| 88    | PN06          | HEX NUT 1/2-12                   |
| 89    | P0506089      | TENSION HANDWHEEL                |

\* Part not shown on breakdown drawing



# G0506X/G0506X3 Parts List

| REF | PART #    | DESCRIPTION                        |
|-----|-----------|------------------------------------|
| 90  | PSS05     | SET SCREW 5/16-18 X 1/4            |
| 91  | P0506091  | TABLE                              |
| 92  | P0506092  | FENCE RAIL                         |
| 93  | PB18      | HEX BOLT 3/8-16 X 1                |
| 94  | PW02      | FLAT WASHER 3/8                    |
| 95  | P0506095  | FENCE                              |
| 96  | P0506096  | FENCE KNOB 3/8-16 X 1 1/4          |
| 97  | P0506097  | TRUNNION                           |
| 98  | PSB19     | CAP SCREW 3/8-16 X 1-1/4           |
| 99  | PLW04     | LOCK WASHER 3/8                    |
| 100 | PB42      | HEX BOLT 1/2-12 X 2                |
| 101 | PW01      | FLAT WASHER 1/2                    |
| 102 | P0506102  | TRUNNION BRACKET                   |
| 103 | PB53      | HEX BOLT 1/2-12 X 1                |
| 104 | PLW07     | LOCK WASHER 1/2                    |
| 105 | P0506105  | BLADE GUIDE FORK                   |
| 106 | PB07      | HEX BOLT 5/16-18 X 3/4             |
| 107 | PW07      | FLAT WASHER 5/16                   |
| 108 | P0506108  | SHAFT CUP                          |
| 109 | PB03      | HEX BOLT 5/16-18 X 1               |
| 110 | PLW01     | LOCK WASHER 5/16                   |
| 111 | P0506111  | LOCK KNOB 3/8-16 X 2-1/4           |
| 112 | P0506112  | GUIDE SHAFT                        |
| 113 | PR19M     | EXT RETAINING RING 28MM            |
| 114 | P0506114  | ELEVATION GEAR SHAFT               |
| 115 | P0506115  | GEAR SHAFT BASE                    |
| 116 | PB07      | HEX BOLT 5/16-18 X 3/4             |
| 117 | PLW01     | LOCK WASHER 5/16                   |
| 118 | P0506118  | GUIDE POST HANDWHEEL               |
| 119 | P0506119  | SPRING KEY M4 X 40                 |
| 120 | P0506120  | BLADE TRACKING KNOB 3/8-16 X 2-1/2 |
| 121 | PN08      | HEX NUT 3/8-16                     |
| 122 | P0506122  | BLADE GUARD                        |
| 123 | P0506123  | BLADE GUARD BRACKET                |
| 124 | PB19      | HEX BOLT 1/4-20 X 1/2              |
| 125 | PLW02     | LOCK WASHER 1/4                    |
| 126 | PW06      | FLAT WASHER 1/4                    |
| 127 | P0506127  | BLADE GUIDE HOLDER                 |
| 128 | PB03      | HEX BOLT 5/16-18 X 1               |
| 129 | PW07      | FLAT WASHER 5/16                   |
| 130 | PB07      | HEX BOLT 5/16-18 X 3/4             |
| 131 | P0506131  | ADJUSTMENT BRACKET                 |
| 132 | P0506132  | BRACKET ARBOR                      |
| 133 | P0506X133 | BLADE GUIDE BASE                   |
| 136 | P0506X136 | GUIDE BEARING SHAFT                |

| REF   | PART #     | DESCRIPTION                        |
|-------|------------|------------------------------------|
| 138   | P6202      | BALL BEARING 6202ZZ*               |
| 139   | P0506139   | SLIDING BASE*                      |
| 140   | P0506140A  | COMPLETE MITER GAUGE               |
| 140-1 | P0506140   | MITER GAUGE BODY                   |
| 141   | P0506141   | T-SLOT WASHER 13MM                 |
| 142   | PFH03      | FLAT HD SCR 1/4-20 X 1/2           |
| 143   | P0506143   | MITER BAR                          |
| 144   | P0506X144  | SPECIAL BOLT 1/4-20 X 5/8          |
| 145   | P0506145   | STOP PIN                           |
| 146   | P0506146   | BLOCK                              |
| 147   | P0506147   | INDICATOR                          |
| 148   | PS29       | PHLP HD SCR 6-32 X 5/8             |
| 149   | PS06       | PHLP HD SCR 10-24 X 3/8            |
| 150   | P0506150   | HANDLE 5/16-18 X 1-1/2             |
| 151   | PW07       | FLAT WASHER 5/16                   |
| 152   | PN12       | HEX NUT 6-32                       |
| 160   | G8589      | GRIZZLY NAMEPLATE-LARGE            |
| 161   | PHTEK10M   | TAP SCREW M4 X 11                  |
| 162   | P0506X162  | G0506X ID LABEL                    |
| 162   | P0506X3162 | G0506X3 ID LABEL                   |
| 163   | PLABEL-14  | ELECTRICITY LABEL                  |
| 164   | PLABEL-18  | UNPLUG BANDSAW LABEL 2" X 3-5/16"H |
| 165   | PLABEL-19  | HANDS/BS BLADE 2" X 3-5/16"H       |
| 166   | PLABEL-20  | DONT OPEN 2"W X 3-5/16"H           |
| 167   | PLABEL-12  | READ MANUAL 2" X 3-5/16"           |
| 168   | PLABEL-11  | SAFETY GLASSES 2" X 3-5/16"        |
| 169   | PLABEL-21  | BS MOVING/ADJUST 2 X 3-5/16"H      |
| 174   | P0506174   | THRUST BEARING SHAFT               |
| 175   | P6202RS    | BEARING RUBBER SHIELD 6202         |
| 176   | PEC05M     | E-CLIP 15MM                        |
| 177   | P0506177   | CABLE CLIP                         |
| 178   | P0506178   | CABLE NUT 6-32                     |
| 179   | PS37       | PHLP HD SCR 6-32 X 5/16            |
| 180   | PS06       | PHLP HD SCR 10-24 X 3/8            |
| 181   | P0506181   | TERMINAL BLOCK                     |
| 182   | P0506182   | STUD 10-24 X 2 1/2                 |
| 183   | PN07       | HEX NUT 10-24                      |
| 184   | PW03       | FLAT WASHER 10-24                  |
| 185   | PSW10      | STRAIN RELIEF 3/4                  |
| 186   | P0506186   | TERMINAL BOX                       |
| 189   | P0506189   | POWER CORD                         |
| 190   | P0506X190  | LIFTING RING 10MM                  |
| 191   | P0506X191  | G0506X MODEL NUMBER LABEL          |
| 191   | P0506X3191 | G0506X3 MODEL NUMBER LABEL         |

\* Part not shown on breakdown drawing

## WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com) to order new labels.

