


H7950 PARTS BREAKDOWN



*Not Shown: # 69 Pallet Tip, #70 Siding Tip, #71 Decking Tip, #98 Nailer Case, #100 Included Pneumatic Oil, #101 Hex Wrench 4mm, #102 Hex Wrench 5mm, #103 Piston Repair Kit, #104 Machine Label.

H7950 PARTS LIST

PAGE 1 OF 2

REF	PART #	DESCRIPTION
1	PFH06M	FLAT HD CAP SCR M6-1 X 20
2	PH7949002	FRONT BRACKET
3	PH7950003	EXHAUST COVER
4	PH7949004	EXHAUST FILTER
5	PH7950005	EXHAUST FILTER PLATE
6	PSB06M	CAP SCREW M6-1 X 25
7	PH7950007	CAP
8	PH7949008	SPRING
9	PH7949009	WASHER
10	PH7949010	O-RING
11	PH7949011	PISTON HEAD VALVE
12	PH7949012	O-RING
13	PH7949013	SEAL
14	PH7949014	PLAIN WASHER
15	PH7949015	PISTON STOPPER
16	PH7950016	O-RING
17	PH7950017	PISTON
18	PH7950018	DRIVER
19	PH7950019	CYLINDER
20	PH7950020	O-RING
21	PH7950021	CYLINDER RING
22	PH7950022	COLLAR
23	PH7950023	O-RING
24	PH7950024	GASKET
25	PH7950025	BODY
26	PH7949026	PAD
27	PH7949027	O-RING
28	PH7950028	BOTTOM BUMPER
29	PH7949029	O-RING
30	PH7950030	NOSE
31	PSB14M	CAP SCREW M8-1.25 X 20
32	PH7949032	STEPPED PIN
33	PH7949033	RETAIN RUBBER
34	PH7949034	RETAIN RUBBER
35	PH7949035	CHECK PAWL
36	PH7949036	SPRING
37	PH7949037	STEPPED PIN
38	PH7950038	PROTECTOR
39	PH7949039	FEED PAWL

REF	PART #	DESCRIPTION
40	PH7949040	STEPPED PIN
41	PH7949041	O-RING
42	PH7949042	FEED PISTON
43	PH7949043	O-RING
44	PH7949044	SPRING
45	PH7949045	SPRING
46	PH7949046	FEED PISTON STOP
47	PH7949047	SPRING COLLAR
48	PH7949048	O-RING
49	PH7950049	STEPPED PIN
50	PH7949050	RATCHET
51	PH7949051	SPRING
52	PH7950052	DOOR
53	PH7949053	NAIL SUPPORT
54	PH7949054	SPRING
55	PH7949055	SET SHAFT
56	PH7949056	SLIDE ROD
57	PH7950057	MAGAZINE
58	PSBS09M	BUTTON HD CAP SCR M5-.8 X 12
59	PSB15M	CAP SCREW M5-.8 X 20
60	PLN02M	LOCK NUT M5-.8
61	PH7949061	MAGAZINE COVER
62	PRP42M	ROLL PIN 3 X 20
63	PH7949063	RUBBER INSERT
64	PH7950064	SAFETY LEVER
65	PH7949065	DUST COVER
66	PW03M	FLAT WASHER 6MM
67	PSBS06M	BUTTON HD CAP SCR M5-.8 X 12
68	PH7950068	NOSE COVER
69	PH7950069	PALLET TIP
70	PH7950070	SIDING TIP
71	PH7950071	DECKING TIP
72	PRP97M	ROLL PIN 3 X 30
73	PH7949073	TRIGGER VALVE CAP
74	PH7949074	O-RING
75	PH7949075	PLUNGER
76	PH7949076	SPRING
77	PH7949077	O-RING
78	PH7949078	O-RING

H7950 PARTS LIST

PAGE 2 OF 2

REF PART #	DESCRIPTION
79	PH7949079 PILOT VALVE
80	PH7949080 O-RING
81	PH7949081 BALL PIN
82	PH7949082 TRIGGER VALVE HOUSING
83	PH7949083 O-RING
84	PH7949084 O-RING
85	PH7949085 TRIGGER PLATE
86	PH7949086 TRIGGER
87	PRP98M ROLL PIN 3 X 16
88	PH7949088 SLIDE SHAFT
89	PH7949089 SPRING
90	PH7949090 TRIP GUIDE
91	PH7949091 SPRING

REF PART #	DESCRIPTION
92	PH7949092 CONTACT TRIP BLOCK
93	PH7949093 ADJUSTING BOLT
94	PH7950094 COVER
95	PH7949095 O-RING
96	PH7949096 RUBBER GRIP
97	PH7949097 ADJUSTING NUT
98	PH7950098 NAILER CASE
100	PH7949100 INCLUDED PNEUMATIC OIL
101	PAW04M HEX WRENCH 4MM
102	PAW05M HEX WRENCH 5MM
103	PH7950103 PISTON REPAIR KIT
104	PH7950104 MACHINE LABEL
105	PH7950105 SPRING